



NETGEAR®

Cable/DSL ProSafe Wireless VPN Security Firewall FVM318


Quick Installation Guide

Follow these quick steps to install your firewall.

Before you begin, be sure you have the configuration parameters from your ISP handy.


1 Connect the Firewall

- Turn off your computer and Cable or DSL Modem.
- Disconnect the Ethernet cable (A) from your computer which connects to your Cable or DSL Modem.




Cable or DSL modem

- Connect the Ethernet cable (A) from your Cable or DSL Modem to the FVM318 firewall's Internet port.



FVM318 Wireless VPN Security Firewall

- Connect the Ethernet cable (B) which came with the firewall from a Local port on the router to your computer.



FVM318 Wireless VPN Security Firewall

- Turn on the Cable or DSL Modem and wait about 30 seconds for the lights to stop blinking.

2 Log In to the Firewall

Note: To connect to the firewall, your computer needs to be configured to obtain an IP address automatically via DHCP. If you need instructions on how to do this, please refer to the *Reference Manual* on the CD which came with your firewall.

- Turn on the firewall and wait for the test light to stop blinking.
- Now, turn on your computer and use a browser like Internet Explorer or Netscape to connect to <http://192.168.0.1>



Note: If you usually run software to log in to your Internet connection, do not run that software.

- For security reasons, the firewall has its own user name and password. When prompted, enter **admin** for the firewall User Name and **password** for the firewall Password, both in lower case letters.

Setup Wizard

System Can Now Detect The Connection Type Of WAN Port, Or You Can Configure It By Yourself.

Do You Want System To Detect The Connection Type?

Yes.
 No. I Want To Configure By Myself.

Next

3 Connect to the Internet

- You are now connected to the firewall. Click the **Yes** button in the *Setup Wizard*.
- Click **Next** to follow the steps in the *Setup Wizard* to input the configuration parameters from your ISP to connect to the Internet.

Note: For wireless configuration or if you had problems connecting, please refer to the *Reference Manual* on the CD which came with the firewall.

Technical Support

PLEASE REFER TO THE SUPPORT INFORMATION CARD THAT SHIPPED WITH YOUR PRODUCT.

By registering your product at www.NETGEAR.com/register, we can provide you with faster expert technical support and timely notices of product and software upgrades.

NETGEAR, INC.

Support Information

Phone: 1-888-NETGEAR (For US & Canada only)

For other countries see your Support information card.

E-mail: Support@NETGEAR.com

Website: www.NETGEAR.com

©2002 by NETGEAR, Inc. All rights reserved.

NETGEAR and Auto Uplink are trademarks or registered trademarks of NETGEAR, Inc. in the United States and/or other countries.

Other brand and product names are trademarks or registered trademarks of their respective holders.

Information is subject to change without notice.



M 1 - F V M 3 1 8 N A - 0

October 2002

Statement of Conditions

In the interest of improving internal design, operational function, and/ or reliability, NETGEAR reserves the right to make changes to the products described in this document without notice.

NETGEAR does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Federal Communications Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm (8 inches) during normal operation.

EN 55 022 Declaration of Conformance

This is to certify that the Model FVM318 Cable/DSL ProSafe Wireless VPN Security Firewall is shielded against the generation of radio interference in accordance with the application of Council Directive 89/ 336/ EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class B (CISPR 22).

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (Model FVM318 ProSafe Wireless VPN Security Firewall) does not exceed the Class B limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (Model FVM318 ProSafe Wireless VPN Security Firewall) respecte les limites de bruits radioélectriques visant les appareils numériques de classe B prescrites dans le règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

Bestätigung des Herstellers/ Importeurs

Es wird hiermit bestätigt, daß das Modell FVM318 Cable/DSL ProSafe Wireless VPN Security Firewall gemäß der im BMPT- AmtsblVfg 243/ 1991 und Vfg 46/ 1992 aufgeführten Bestimmungen entspricht. Das vorschriftsmäßige Betreiben einiger Geräte (z. B. Testsender) kann jedoch gewissen Beschränkungen unterliegen. Lesen Sie dazu bitte die Anmerkungen in der Betriebsanleitung.

Das Bundesamt für Zulassungen in der Telekommunikation wurde davon unterrichtet, daß dieses Gerät auf den Markt gebracht wurde und es ist berechtigt, die Serie auf die Erfüllung der Vorschriften hin zu überprüfen.

Certificate of the Manufacturer/ Importer

It is hereby certified that the Model FVM318 Cable/DSL ProSafe Wireless VPN Security Firewall has been suppressed in accordance with the conditions set out in the BMPT- AmtsblVfg 243/ 1991 and Vfg 46/ 1992. The operation of some equipment (for example, test transmitters) in accordance with the regulations may, however, be subject to certain restrictions. Please refer to the notes in the operating instructions.

Federal Office for Telecommunications Approvals has been notified of the placing of this equipment on the market and has been granted the right to test the series for compliance with the regulations.

Voluntary Control Council for Interference (VCCI) Statement

This equipment is in the second category (information equipment to be used in a residential area or an adjacent area thereto) and conforms to the standards set by the Voluntary Control Council for Interference by Data Processing Equipment and Electronic Office Machines aimed at preventing radio interference in such residential areas.

When used near a radio or TV receiver, it may become the cause of radio interference.

Read instructions for correct handling.